MEBS6008 Environmental Services II

http://www.mech.hku.hk/bse/MEBS6008/



Fans and Pumps I



Dr. Sam C. M. Hui

Department of Mechanical Engineering
The University of Hong Kong
E-mail: cmhui@hku.hk

Contents



Centrifugal Pumps


Pump Arrangements

Matching Pumps to Systems






- Centrifugal pump
 - Most widely used in HVAC applications, e.g.
 - Hot water systems
 - Chilled water systems
 - Condenser water systems
 - Boiler feed and condensate return pumps
 - Operation
 - Electric motor's output torque => impeller's rotation
 - Coupling to the pump shaft
 - Centrifugal force & tip speed force




Chilled water pumping system




Pump motor

Centrifugal pump body



A double-suction, horizontal split-case, single-stage centrifugal pump

(Source: Wang, S. K., 2001. Handbook of Air Conditioning and Refrigeration)



- 1 Casing
- 2 Impeller
- 6 Shaft, pump
- 8 Ring, impeller
- 9 Cover, suction
- 11 Cover, stuffing box
- 14 Sleeve, shaft
- 16 Bearing, inboard


- 17 Gland
- 18 Bearing, outboard
- 19 Frame
- 21 Liner, frame
- 22 Locknut, bearing
- 25 Ring, suction cover
- 26 Screw, impeller
- 27 Ring, stuffing box cover

- 28 Gasket, impeller screw
- 32 Key, impeller
- 37 Cover, bearing, outboard
- 38 Gasket, shaft-sleeve
- 40 Deflector
- 49 Seal, bearing cover, outboard
- 51 Retainer, grease

- 62 Thrower, oil or grease
- 65 Seal, mechanical, stationary element
- 67 Shim, frame-liner
- 69 Lock washer
- 78 Spacer, bearing
- 80 Seal, mechanical, rotating element


Typical overhung-impeller end-suction pump


(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)




Centrifugal pump

(Source: ASHRAE HVAC Systems and Equipment Handbook 2012)





Impeller action on fluid




Flow pattern of impeller/volute action







- Types of centrifugal pumps
 - Circulator pump
 - Closed-couple end suction pump
 - Frame-mounted end suction pump
 - Base-mounted horizontal split case pump
 - Vertical inline pump
 - Vertical turbine single or multistage pump




Circulation pump




Close-coupled end suction pump




Frame-mounted end suction pump




Base-mounted horizontal split case pump






Vertical turbine pump, wet sump arrangement



Base plate-mounted centrifugal pump installation

(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)



In-line pump installation


(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)





- Variable speed pumps
 - Less expensive nowadays
- Centrifugal pump characteristics
 - Total pressure-capacity curve
 - Flat curve: applied on closed piping systems with modulating valves
 - Steep curve: usually for open piping systems (cooling towers), w/ high pressure, constant flow
 - Family of pump performance curves

Total Pressure, kPa



Capacity, L/s


Total pressure-capacity curve

Steep-Total Pressure, kPa Flat -


What does this imply?

Capacity, L/s

Flat versus steep pump curves



Characteristic curves for pump models




Selected pump pressure-capacity curve






- System pressure characteristic curve
 - Compared w/: fan-duct system characteristics
 - System operating point: intersection of fan curve
 & system curve
- Pump power (W) = flow (L/s) x pressure (kPa)
 - Pump input power
 - Pump efficiency
 - Matching pump to system curve
 - Best efficiency point




(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)






Capacity, L/s

Increase of pumping power required with pump flow



Capacity, L/s

Pump efficiency








- Similarity relationships
 - Pump affinity laws (c.f. fan laws)

Function	Speed change	Impeller diameter change
		51111186
Flow	$Q_2 = Q_1 (N_2/N_1)$	$Q_2 = Q_1 \left(D_2 / D_1 \right)$
Daggarag	$\sim -10 (NI/NI)^2$	$\sim - \sim (D/D)^2$
Pressure	$p_2 = p_1 \ (N_2/N_1)^2$	$p_2 = p_1 (D_2/D_1)^2$
Power	$P_2 = P_1 (N_2/N_1)^3$	$P_2 = P_1 (D_2/D_1)^3$

Centrifugal Pumps



- Pump affinity laws (example)
 - A pump is rated at 15 L/s at 200 kPa with a 24 rpm electric motor. What is the flow and pressure if used with a 16 rps motor? Assume no system static pressure.
 - Solution:
 - Flow: $Q_2 = Q_1 (N_2/N_1) = 15 (16/24) = 10 L/s$
 - Pressure: $p_2 = p_1 (N_2/N_1)^2 = 200 (16/24)^2 = 88.9 \text{ kPa}$





(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)





- Radial thrust
 - Non-uniform pressure around impeller
 - Greatest at shutoff
 - Decreases from shutoff to design capacity
 - Increase with overcapacity
- Net positive suction (NPS)
 - Cavitation: vapour pockets form in impeller passages & may cause damages
 - Net positive suction required (NPSR) pump






Uniform Pressures Exist at Design Capacity

Non-Uniform Pressures Exist at Reduced Capacities

Pressures on impeller causing radial thrust



Change in radial thrust versus pumping rate

Centrifugal Pumps



- Net positive suction available (NPSA)
 - For the installation
 - Total useful energy above the vapour pressure at the pump suction connection
 - Affected by the location of expansion tank
- If NPSA < Pump's NPSR
 - Cavitation, noise, inadequate pumping, etc.
 - Avoid problem, NPSA > NPSR






Fig. 29 Net Positive Suction Pressure Available




Test setup to determine pump's NPSR








- Pump design criteria
 - Design flow & minimum system flow
 - Pressure drop required for the most resistant loop
 - System pressure at maximum and minimum flows
 - Type of control valve—two-way or three-way
 - Continuous or variable flow
 - Pump environment, number of pumps and standby
 - Electric voltage and current
 - Electric service and starting limitations
 - Motor quality versus service life
 - Water treatment, water conditions, and material selection








- Pump selection process
 - Determine the load to be pumped
 - Determine design Δt & calculate required flow
 - Sum up the load flows to determine total flow
 - Determine the "critical path" (most resistant)
 - Determine mounting method & support
 - Select a pump from manufacturer
 - Flat curve & steep curve, pump operation & motor
 - Check overflow capacity when staging multiple pumps











- Pumping arrangements & control scenarios
 - Multiple pumps in parallel or series
 - Standby pump
 - Pumps with two-speed motors
 - Primary-secondary pumping
 - Variable-speed pumping
 - Distributed pumping



Flow Pump curve for parallel operation



Flow

Operating conditions for parallel pump installation




Fig. 34 Construction of Curve for Dissimilar Parallel Pumps






Fig. 35 Typical Piping for Parallel Pumps



Pump curve for series operation








Fig. 38 Typical Piping for Series Pumps


Matching Pumps to Systems

- Good piping system design
 - Match system characteristics to pump curve
- Trimming pump impellers
 - To reduce flow
 - To match partload requirments
- Pump control
 - Two-speed pumping & motors
 - Variable speed pumping




System Flow Typical system curve





Flow Rate Shift of system curves



A OVERPRESSURE WITH TRIMMED CONSTANT-SPEED PUMP

B OVERPRESSURE WITH CONSTANT-SPEED PUMP





Fig. 39 Example of Two Parallel Pumps with Two-Speed Motors

Matching Pumps to Systems


- Modulation of pump-piping systems
 - Throttle volume flow by using a valve
 - Change flow resistance new system curve
 - Also known as "riding on the curve"
 - Turn water pumps on or off in sequence
 - Sudden increase/drop in flow rate and head
 - Vary the pump speed
 - System operating point move along the system curve
 - Requires the lowest pump power input



(Source: ASHRAE HVAC Systems and Equipment Handbook 2004)

Matching Pumps to Systems

- Plant loop (at constant flow) (production loop)
 - To protect evaporator from freezing, a fairly constant-volume water flow is required
- Building loop (at variable flow)
 - For saving energy at partload
 - A differential pressure transmitter is often installed at the farthest end from the pump
- Primary-secondary loop
 - A short common pipe connects the 2 loops



Primary-secondary loop and pumping






Fig. 40 Primary-Secondary Pumping



Constant flow chilled water system



Variable flow chilled water system (plant-building loop)






FIGURE 7.21 Schematic diagram of a plant-distributed pumping loop.


(Source: Wang, S. K., 2001. Handbook of Air Conditioning and Refrigeration)




Primary-secondary variable speed pumping



Distributed variable speed pumping



Chilled water system using a plant-distribution-building loop



Matching Pumps to Systems

- Chiller plant operation/performance management
 - Parallel chiller arrangement
 - Series chiller arrangement
 - Decoupled chiller arrangement
 - Chiller plant control
 - Tertiary pumping